

Betriebsanleitung:

Steckernetzteile (SYS 1196– Serie)

Zu Ihrer Sicherheit:

- das Netzteil ist weder spritzwassergeschützt noch wasserdicht.
- das Netzteil darf nicht im Bad, in Feuchträumen oder im Freien betrieben werden
- die Eingangsspannung zwischen 90VAC bis 264VAC/47-63Hz. Muss zwingend eingehalten werden
- das Netzteil darf keiner direkten Sonnenbestrahlung ausgesetzt oder sonstigen Wärmequellen ausgesetzt werden
- öffnen Sie nicht das Gehäuse, das Netzteil ist wartungsfrei

Die Angaben auf dem Datenblatt sind zwingend einzuhalten!

Instruction Manual:

Wall Mount Power Supply (SYS 1196– Serie)

For your security

- the power supply is neither splash proof or waterproof
- do not use the power supply in bathroom, in rooms with high humidity or Outdoors
- only use the correct power outlet voltage. The input voltage must be held in the range of 90VAC bis 264VAC/47-63Hz
- do not expose the power supply to heat or direct sunshine
- do not remove the units cover, there are no serviceable parts inside

Abiding the technical specifications of the data sheet is mandatory