

CAR-DEHUMIDIFIER

Use

Pingi Car-Dehumidifier offers a quick and easy way to remove dampness from your car, caravan, RV and boat. It is your best choice against fogged up windshields and other moisture related problems. Car-Dehumidifier attracts the excess humidity in your vehicle like a magnet. The absorbed water is safely retained without ever leaking out during use. And the best thing? It does not need refills!

Need to recharge it? Just heat it in the microwave

When Car-Dehumidifier is full of moisture it needs recharging. It tells you this on the special indicator, which turns from blue to light-pink. Make sure not to place the product directly on the metal grate or on the glass plate. Place it on a microwave-safe plate and a paper towel. Heat Moisture Killer in the microwave for 6 minutes at approx. 600 Watt. Make sure the indicator faces upwards. During recharging, the moisture will evaporate hygienically from the product. You can also recharge the product in the sun or on top of a radiator, but this takes longer. After recharging, the indicator turns back to blue. Moisture Killer will then be ready for use again.

- Please remove the plastic bag before first use and keep it away from children.
- Contains small parts which may cause choking if misused. Keep out of reach of children.
- Avoid rubbing or scratching the indicator.
- The indicator colour can change after several recharges, depending on the ventilation of your microwave. This does not affect the effectiveness of the product.

Attention when using microwave

- 1) Recharge the product only when the indicator is clearly pink.
- 2) After recharging, allow the product to cool down before handling, as it gets very hot in the microwave.
- 3) Avoid contact with oil, grease or water. Your microwave must be clean. Don't touch the moist indicator. Not suitable for recharging in traditional ovens.)
- 4) Do not place the product directly on metal shelves, glass plates or surfaces in the microwave. They can burn the fabric.
- 5) Recharge only one product at a time. Remove all excess water when using the microwave twice.

