

## Compatible Notebook Computers Model List

The Setup Procedures of the power adapter could be founded in the User Manual. From this page, you could easily find what "Tip" and "Voltage Selection Device" is suitable for your Notebook Computer model.

Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.
ACER	TravelMate 200 Series, 200DX/T	Green(19V)	E	ASUS	T7200	Green(19V)	E	COMPAQ	LTE 5300	Red(18V)	D	COMPAQ	Presario 1274	Green(19V)	C	COMPAQ	Presario 1830	Green(19V)	C	DELL	Latitude C810 Series	Black(20V)	F
ACER	TravelMate 340 Series, 340T	Green(19V)	E	ASUS	T9000 Series	Green(19V)	E	COMPAQ	LTE 5380	Red(18V)	D	COMPAQ	Presario 1275	Green(19V)	C	COMPAQ	Presario 2700	Green(19V)	C	DELL	Latitude CP Series	Black(20V)	F
ACER	TravelMate 505 Series, 505DX	Green(19V)	E	COMPAQ	Armada 100	Red(18V)	D	COMPAQ	LTE 5400	Red(18V)	D	COMPAQ	Presario 1277	Green(19V)	C	COMPAQ	Presario 300	Red(18V)	E	DELL	Latitude CPI 366XT	Black(20V)	F
ACER	TravelMate 520 Series, 520IT	Green(19V)	E	COMPAQ	Armada 110	Red(18V)	D	COMPAQ	LTE 5480	Red(18V)	D	COMPAQ	Presario 1278	Green(19V)	C	COMPAQ	Presario 305	Red(18V)	E	DELL	Latitude CPI A400XT	Black(20V)	F
ACER	TravelMate 600 Series	Green(19V)	E	COMPAQ	Armada 1100	Red(18V)	D	COMPAQ	LTE 6000	Red(18V)	D	COMPAQ	Presario 1279	Green(19V)	C	COMPAQ	Presario 305	Red(18V)	E	DELL	Latitude CPI Series	Black(20V)	F
ACER	TravelMate 730 Series	Green(19V)	E	COMPAQ	Armada 1120	Red(18V)	D	COMPAQ	Presario 1010	Green(19V)	C	COMPAQ	Presario 1450	Green(19V)	C	COMPAQ	Presario 800	Green(19V)	C	DELL	Latitude CPi300ST	Black(20V)	F
ACER	TravelMate 350	Green(19V)	E	COMPAQ	Armada 1125	Red(18V)	D	COMPAQ	Presario 1020	Green(19V)	C	COMPAQ	Presario 1600 Series	Green(19V)	C	COMPAQ	Prosignia 170	Red(18V)	E	DELL	Latitude CPi300XT	Black(20V)	F
AMI	TF6720, TF6760, FT8850	Green(19V)	C	COMPAQ	Armada 1130	Red(18V)	D	COMPAQ	Presario 1030	Green(19V)	C	COMPAQ	Presario 1600i	Green(19V)	C	COMPAQ	Prosignia 190	Red(18V)	E	DELL	Latitude CPt Series	Black(20V)	F
APPLE	iBook G3	Orange(24V)	G	COMPAQ	Armada 4100	Red(18V)	D	COMPAQ	Presario 1060	Green(19V)	C	COMPAQ	Presario 1610	Green(19V)	C	DELL	Inspiron 2500	Black(20V)	F	DELL	Latitude CPx H500GT	Black(20V)	F
APPLE	Power Book 1400 Series	Orange(24V)	G	COMPAQ	Armada 4120	Red(18V)	D	COMPAQ	Presario 1065	Green(19V)	C	COMPAQ	Presario 1611	Green(19V)	C	DELL	Inspiron 2600	Black(20V)	F	DELL	Latitude CPx Series	Black(20V)	F
APPLE	Power Book 2400 Series	Orange(24V)	G	COMPAQ	Armada 4130	Red(18V)	D	COMPAQ	Presario 1070	Green(19V)	C	COMPAQ	Presario 1621	Green(19V)	C	DELL	Inspiron 2650	Black(20V)	F	DELL	Latitude CS/CSx Series	Black(20V)	F
APPLE	Power Book 3400 Series	Orange(24V)	G	COMPAQ	Armada 4131	Red(18V)	D	COMPAQ	Presario 1075	Green(19V)	C	COMPAQ	Presario 1622	Green(19V)	C	DELL	Inspiron 3000	Green(19V)	C	DELL	Latitude M40 workstation	Black(20V)	F
APPLE	Power Book G3	Orange(24V)	G	COMPAQ	Armada 4220	Red(18V)	D	COMPAQ	Presario 1080	Green(19V)	C	COMPAQ	Presario 1625	Green(19V)	C	DELL	Inspiron 3200	Green(19V)	C	DELL	Latitude XP Series: 100cx	Green(19V)	A
ASUS	A1000 Series	Green(19V)	E	COMPAQ	Armada E500 Series	Red(18V)	E	COMPAQ	Presario 1200	Green(19V)	C	COMPAQ	Presario 1626	Green(19V)	C	DELL	Inspiron 3500	Green(19V)	C	DELL	Latitude XP Series: 4100c	Green(19V)	A
ASUS	ArtBook L7336	Green(19V)	E	COMPAQ	Armada E700 Series	Red(18V)	E	COMPAQ	Presario 1210	Green(19V)	C	COMPAQ	Presario 1645	Green(19V)	C	DELL	Inspiron 3700	Black(20V)	F	DELL	Latitude XP Series: 4100D	Green(19V)	A
ASUS	B1000 Series	Green(19V)	E	COMPAQ	Armada M300 Series	Red(18V)	E	COMPAQ	Presario 1215	Green(19V)	C	COMPAQ	Presario 1655	Green(19V)	C	DELL	Inspiron 3800	Black(20V)	F	DELL	Latitude XP Series: 4100T	Green(19V)	A
ASUS	F7400	Green(19V)	E	COMPAQ	Armada M700 Series	Red(18V)	E	COMPAQ	Presario 1220	Green(19V)	C	COMPAQ	Presario 1670	Green(19V)	C	DELL	Inspiron 4000	Black(20V)	F	DELL	Latitude XP Series: 450c	Green(19V)	A
ASUS	L1000B Series	Green(19V)	E	COMPAQ	Armada V300 Series	Red(18V)	E	COMPAQ	Presario 1232	Green(19V)	C	COMPAQ	Presario 1680	Green(19V)	C	DELL	Inspiron 4100	Black(20V)	F	DELL	Latitude XP Series: 450x	Green(19V)	A
ASUS	L2000B Series	Green(19V)	E	COMPAQ	Evo N115	Green(19V)	C	COMPAQ	Presario 1235	Green(19V)	C	COMPAQ	Presario 1681	Green(19V)	C	DELL	Inspiron 4150	Black(20V)	F	DELL	Latitude XP Series: 475c	Green(19V)	A
ASUS	L2000D Series	Green(19V)	E	COMPAQ	Evo N150	Green(19V)	E	COMPAQ	Presario 1236	Green(19V)	C	COMPAQ	Presario 1682	Green(19V)	C	DELL	Inspiron 4200	Black(20V)	F	DELL	Latitude XP Series: 475D	Green(19V)	A
ASUS	L2000E Series	Green(19V)	E	COMPAQ	Evo N160	Green(19V)	C	COMPAQ	Presario 1237	Green(19V)	C	COMPAQ	Presario 1685	Green(19V)	C	DELL	Inspiron 5000	Black(20V)	F	DELL	Latitude Xpi Series	Green(19V)	F
ASUS	L3000C Series	Green(19V)	E	COMPAQ	Evo N180	Green(19V)	C	COMPAQ	Presario 1240	Green(19V)	C	COMPAQ	Presario 1687	Green(19V)	C	DELL	Inspiron 5000e	Black(20V)	F	DELL	LSH 400ST	Black(20V)	F
ASUS	L3000S Series	Green(19V)	E	COMPAQ	Evo N200	Green(19V)	E	COMPAQ	Presario 1244	Green(19V)	C	COMPAQ	Presario 1688	Green(19V)	C	DELL	Inspiron 7000	Green(19V)	C	EPSON	Action Note 800, 866C, 880C/CX	Green(19V)	C
ASUS	L7233	Green(19V)	E	COMPAQ	Evo N400c	Green(19V)	E	COMPAQ	Presario 1245	Green(19V)	C	COMPAQ	Presario 1690	Green(19V)	C	DELL	Inspiron 7500	Black(20V)	F	EPSON	Action Note 890, 890C, 895C	Green(19V)	C
ASUS	L7300	Green(19V)	E	COMPAQ	Evo N410c	Green(19V)	E	COMPAQ	Presario 1247	Green(19V)	C	COMPAQ	Presario 1692	Green(19V)	C	DELL	Inspiron 8000	Black(20V)	F	EPSON	Action Note 900, 910C	Green(19V)	C
ASUS	L8400	Green(19V)	E	COMPAQ	Evo N600c	Green(19V)	E	COMPAQ	Presario 1250	Green(19V)	C	COMPAQ	Presario 1693	Green(19V)	C	DELL	Inspiron 8100	Black(20V)	F	EPSON	Endeavor TK-300 Series	Blue(16V)	C
ASUS	M1000 Series	Green(19V)	E	COMPAQ	Evo N800c	Green(19V)	E	COMPAQ	Presario 1255	Green(19V)	C	COMPAQ	Presario 1694	Green(19V)	C	DELL	Latitude 450MC Series	Green(19V)	C	FUJITSU	A Series A4170	Blue(16V)	A
ASUS	M2 Series, M2400	Green(19V)	E	COMPAQ	Evo N800v	Green(19V)	E	COMPAQ	Presario 1260	Green(19V)	C	COMPAQ	Presario 1700 Series	Green(19V)	C	DELL	Latitude C400 Series	Black(20V)	F	FUJITSU	B Series B112	Blue(16V)	A
ASUS	M2000 Series	Green(19V)	E	COMPAQ	LTE 5000	Red(18V)	D	COMPAQ	Presario 1266	Green(19V)	C	COMPAQ	Presario 1800 Series	Green(19V)	C	DELL	Latitude C500 Series	Black(20V)	F	FUJITSU	B Series B142	Blue(16V)	A
ASUS	MP 8xxx Series	Green(19V)	E	COMPAQ	LTE 5150	Red(18V)	D	COMPAQ	Presario 1267	Green(19V)	C	COMPAQ	Presario 1805 Series	Green(19V)	C	DELL	Latitude C600 Series	Black(20V)	F	FUJITSU	B Series B2130	Blue(16V)	A
ASUS	S1000 Series	Green(19V)	E	COMPAQ	LTE 5200	Red(18V)	D	COMPAQ	Presario 1272	Green(19V)	C	COMPAQ	Presario 1810	Green(19V)	C	DELL	Latitude C610 Series	Black(20V)	F	FUJITSU	B Series B2131	Blue(16V)	A
ASUS	T4700CS	Green(19V)	E	COMPAQ	LTE 5250	Red(18V)	D	COMPAQ	Presario 1273	Green(19V)	C	COMPAQ	Presario 1825	Green(19V)	C	DELL	Latitude C800	Black(20V)	F	FUJITSU	C Series C340	Blue(16V)	A

## Compatible Notebook Computers Model List

The Setup Procedures of the power adapter could be founded in the User Manual. From this page, you could easily find what "Tip" and "Voltage Selection Device" is suitable for your Notebook Computer model.

Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.
FUJITSU	C Series C350	Blue(16V)	A	FUJITSU	Lifebook 400 Series	Blue(16V)	A	GATEWAY	Solo 1200 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 500	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3295	Green(19V)	C	IBM	Thinkpad "I" Series 1450l (2611-xxx)	Green(19V)	D
FUJITSU	C Series C352	Blue(16V)	A	FUJITSU	Lifebook 420Dx	Blue(16V)	A	GATEWAY	Solo 1400 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 6000 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3300 Series	Green(19V)	C	IBM	Thinkpad "I" Series 1451l (2611-xxx)	Green(19V)	D
FUJITSU	C Series C360	Blue(16V)	A	FUJITSU	Lifebook 435Dx	Blue(16V)	A	GATEWAY	Solo 1450 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 6100 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3310	Green(19V)	C	IBM	Thinkpad "I" Series 1452l (2611-xxx)	Green(19V)	D
FUJITSU	C Series C4120	Blue(16V)	A	FUJITSU	Lifebook 500 Series	Blue(16V)	A	GATEWAY	Solo 2100 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 7100 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3330	Green(19V)	C	IBM	Thinkpad "I" Series 1460l (2621-xxx)	Blue(16V)	C
FUJITSU	C Series C4235	Blue(16V)	A	FUJITSU	Lifebook 531T	Blue(16V)	A	GATEWAY	Solo 2150 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 7103	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3350	Green(19V)	C	IBM	Thinkpad "I" Series 1470l (2611-xxx)	Green(19V)	D
FUJITSU	C Series C5130	Blue(16V)	A	FUJITSU	Lifebook 535T	Blue(16V)	A	GATEWAY	Solo 2200 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 7150 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3370	Green(19V)	C	IBM	Thinkpad "I" Series 1471l (2611-xxx)	Green(19V)	D
FUJITSU	C Series C5235	Blue(16V)	A	FUJITSU	Lifebook 555Tx	Blue(16V)	A	GATEWAY	Solo 2300 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 900 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3390	Green(19V)	C	IBM	Thinkpad "I" Series 1472l (2611-xxx)	Green(19V)	D
FUJITSU	C Series C6320	Blue(16V)	A	FUJITSU	Lifebook 565Tx	Blue(16V)	A	GATEWAY	Solo 2500 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook VT Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N5000	Green(19V)	C	IBM	Thinkpad "I" Series 1480l (2621-xxx)	Blue(16V)	C
FUJITSU	C Series C6330	Blue(16V)	A	FUJITSU	Lifebook 585Tx	Blue(16V)	A	GATEWAY	Solo 2550 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook XE Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N5100	Green(19V)	C	IBM	Thinkpad "I" Series 1500l (2611-xxx)	Green(19V)	D
FUJITSU	C Series C6525	Blue(16V)	A	FUJITSU	Lifebook 600 Series	Blue(16V)	A	GATEWAY	Solo 3100 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook XE2 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N5125	Green(19V)	C	IBM	Thinkpad "I" Series 1500l (2621-xxx)	Blue(16V)	C
FUJITSU	C Series C6535	Blue(16V)	A	FUJITSU	Lifebook 635T	Blue(16V)	A	GATEWAY	Solo 3150 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook XE3 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N5130	Green(19V)	C	IBM	Thinkpad "R" Series	Blue(16V)	C
FUJITSU	C Series C6547	Blue(16V)	A	FUJITSU	Lifebook 635Tx	Blue(16V)	A	GATEWAY	Solo 5100 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook xe4100	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N5159	Green(19V)	C	IBM	Thinkpad "T" Series, T20, T21, T22	Blue(16V)	C
FUJITSU	C Series C6556	Blue(16V)	A	FUJITSU	Lifebook 655Tx	Blue(16V)	A	GATEWAY	Solo 5150 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook XT	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N5190	Green(19V)	C	IBM	Thinkpad "X" Series, X20, X21, X22	Blue(16V)	C
FUJITSU	C Series C6577	Blue(16V)	A	FUJITSU	Lifebook 656Tx	Blue(16V)	A	GATEWAY	Solo 5300 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion 2105	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N5270	Green(19V)	C	IBM	Thinkpad 1200l	Blue(16V)	C
FUJITSU	C Series C7651	Blue(16V)	A	FUJITSU	Lifebook 675Tx	Blue(16V)	A	GATEWAY	Solo 5350 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion 3000 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N5271	Green(19V)	C	IBM	Thinkpad 240	Blue(16V)	C
FUJITSU	E Series E330	Blue(16V)	A	FUJITSU	Lifebook 690Tx	Blue(16V)	A	GATEWAY	Solo 600 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion 3101	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N5350	Green(19V)	C	IBM	Thinkpad 240X	Blue(16V)	C
FUJITSU	E Series E340	Blue(16V)	A	FUJITSU	Lifebook 700 Series	Blue(16V)	A	GATEWAY	Solo 9100 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion 4101	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion VT Series	Green(19V)	C	IBM	Thinkpad 290	Blue(16V)	C
FUJITSU	E Series E342	Blue(16V)	A	FUJITSU	Lifebook 735Dx	Blue(16V)	A	GATEWAY	Solo 9300 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion 4103	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion XH156	Green(19V)	C	IBM	Thinkpad 310	Green(19V)	D
FUJITSU	E Series E350	Blue(16V)	A	FUJITSU	Lifebook 755Tx	Blue(16V)	A	GATEWAY	Solo 9500	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion 4105	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion XT Series	Green(19V)	C	IBM	Thinkpad 310D	Green(19V)	D
FUJITSU	E Series E351	Blue(16V)	A	FUJITSU	Lifebook 756Dx	Blue(16V)	A	GATEWAY	Solo 9550	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion 5159	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion ZE	Green(19V)	C	IBM	Thinkpad 310E	Green(19V)	D
FUJITSU	E Series E360	Blue(16V)	A	FUJITSU	Lifebook 765Tx	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 1000	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion 6100 Series	Green(19V)	C	HITACHI	Flora prius 20L	Green(19V)	A	IBM	Thinkpad 310ED	Green(19V)	D
FUJITSU	E Series E362	Blue(16V)	A	FUJITSU	Lifebook 770Tx	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 2100 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3100 Series	Green(19V)	C	HITACHI	Flora prius 210, 220N	Blue(16V)	C	IBM	Thinkpad 365	Blue(16V)	C
FUJITSU	E Series E370	Blue(16V)	A	FUJITSU	Lifebook 790Tx	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 2103	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3110	Green(19V)	C	HITACHI	Vision Book E & MX series	Green(19V)	C	IBM	Thinkpad 365XD	Blue(16V)	C
FUJITSU	E Series E380	Blue(16V)	A	FUJITSU	Lifebook 900 Series	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 2105	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3150	Green(19V)	C	HITACHI	Vision Book Pro, Elite, Plus	Green(19V)	C	IBM	Thinkpad 380	Blue(16V)	C
FUJITSU	E Series E6540	Blue(16V)	A	FUJITSU	Lifebook 985Tx	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 3000 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3190	Green(19V)	C	IBM	Thinkpad "A" Series, A20, A21	Blue(16V)	C	IBM	Thinkpad 380D	Blue(16V)	C
FUJITSU	E Series E6556	Blue(16V)	A	FUJITSU	Lifebook 990Tx2	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 3100 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3200 Series	Green(19V)	C	IBM	Thinkpad "I" Series 1410l (2611-xxx)	Green(19V)	D	IBM	Thinkpad 380E	Blue(16V)	C
FUJITSU	E Series E6570	Blue(16V)	A	FUJITSU	Lifebook P1000	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 3101	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3210	Green(19V)	C	IBM	Thinkpad "I" Series 1411l (2611-xxx)	Green(19V)	D	IBM	Thinkpad 380ED	Blue(16V)	C
FUJITSU	L Series L440	Blue(16V)	A	FUJITSU	Lifebook P2000	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 4100 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3215	Green(19V)	C	IBM	Thinkpad "I" Series 1412l (2611-xxx)	Green(19V)	D	IBM	Thinkpad 380XD	Blue(16V)	C
FUJITSU	L Series L470	Blue(16V)	A	FUJITSU	S Series S4510	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 4101	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3220	Green(19V)	C	IBM	Thinkpad "I" Series 1420l (2621-xxx)	Blue(16V)	C	IBM	Thinkpad 380Z	Blue(16V)	C
FUJITSU	Lifebook 200 Series	Blue(16V)	A	FUJITSU	S Series S452	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 4103	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3250	Green(19V)	C	IBM	Thinkpad "I" Series 1434l (2611-xxx)	Green(19V)	D	IBM	Thinkpad 385	Blue(16V)	C
FUJITSU	Lifebook 270Dx	Blue(16V)	A	FUJITSU	S Series S-4542	Blue(16V)	A	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 4105	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3270	Green(19V)	C	IBM	Thinkpad "I" Series 1435l (2611-xxx)	Green(19V)	D	IBM	Thinkpad 385D	Blue(16V)	C
FUJITSU	Lifebook 280Dx	Blue(16V)	A	GATEWAY	Solo 1150 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	OmniBook 4150 Series	Green(19V)	C	HEWLETT PACKARD HEWLETT PACKARD	Pavilion N3290	Green(19V)	C	IBM	Thinkpad "I" Series 1436l (2611-xxx)	Green(19V)	D	IBM	Thinkpad 385ED	Blue(16V)	C

## Compatible Notebook Computers Model List

The Setup Procedures of the power adapter could be founded in the User Manual. From this page, you could easily find what "Tip" and "Voltage Selection Device" is suitable for your Notebook Computer model.

Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.
IBM	Thinkpad 385XD	Blue(16V)	C	PANASONIC	CF45	Blue(16V)	A	SONY	VAIO PCG-505G	Blue(16V)	A	SONY	VAIO PCG-F390	Green(19V)	A	SONY	VAIO PCG-R505TEK	Green(19V)	A	SONY	VAIO PCG-Z505JEK	Green(19V)	A
IBM	Thinkpad 390	Blue(16V)	C	PANASONIC	CF47	Blue(16V)	A	SONY	VAIO PCG-505GX	Blue(16V)	A	SONY	VAIO PCG-F400LT	Green(19V)	A	SONY	VAIO PCG-R505TS	Green(19V)	A	SONY	VAIO PCG-Z505JS	Green(19V)	A
IBM	Thinkpad 390E	Blue(16V)	C	PANASONIC	CF48	Blue(16V)	A	SONY	VAIO PCG-505TR	Blue(16V)	A	SONY	VAIO PCG-F403	Green(19V)	A	SONY	VAIO PCG-SR11K	Blue(16V)	A	SONY	VAIO PCG-Z505JSK	Green(19V)	A
IBM	Thinkpad 390X	Blue(16V)	C	PANASONIC	CF61	Blue(16V)	A	SONY	VAIO PCG-505TS	Blue(16V)	A	SONY	VAIO PCG-F409	Green(19V)	A	SONY	VAIO PCG-SR17	Blue(16V)	A	SONY	VAIO PCG-Z505LE	Green(19V)	A
IBM	Thinkpad 560	Blue(16V)	C	PANASONIC	CF62	Blue(16V)	A	SONY	VAIO PCG-505TX	Blue(16V)	A	SONY	VAIO PCG-F420	Green(19V)	A	SONY	VAIO PCG-SR17K	Blue(16V)	A	SONY	VAIO PCG-Z505LEK	Green(19V)	A
IBM	Thinkpad 560E	Blue(16V)	C	PANASONIC	CF63	Blue(16V)	A	SONY	VAIO PCG-700 Series	Green(19V)	A	SONY	VAIO PCG-F430	Green(19V)	A	SONY	VAIO PCG-SR1K	Blue(16V)	A	SONY	VAIO PCG-Z505LS	Green(19V)	A
IBM	Thinkpad 560X	Blue(16V)	C	PANASONIC	CF71	Blue(16V)	A	SONY	VAIO PCG-705	Green(19V)	A	SONY	VAIO PCG-F450	Green(19V)	A	SONY	VAIO PCG-SR21K	Blue(16V)	A	SONY	VAIO PCG-Z505LSK	Green(19V)	A
IBM	Thinkpad 560Z	Blue(16V)	C	PANASONIC	CF72	Blue(16V)	A	SONY	VAIO PCG-707	Green(19V)	A	SONY	VAIO PCG-F480	Green(19V)	A	SONY	VAIO PCG-SR5K	Blue(16V)	A	SONY	VAIO PCG-Z505R	Green(19V)	A
IBM	Thinkpad 570	Blue(16V)	C	PANASONIC	Toughbook 37	Blue(16V)	A	SONY	VAIO PCG-717	Green(19V)	A	SONY	VAIO PCG-F480K	Green(19V)	A	SONY	VAIO PCG-SR7K	Blue(16V)	A	SONY	VAIO PCG-Z505RX	Green(19V)	A
IBM	Thinkpad 600	Blue(16V)	C	PHILLIPS	F76000 Series	Green(19V)	D	SONY	VAIO PCG-719	Green(19V)	A	SONY	VAIO PCG-F490K	Green(19V)	A	SONY	VAIO PCG-SR9G	Blue(16V)	A	SONY	VAIO PCG-Z505S	Green(19V)	A
IBM	Thinkpad 600E	Blue(16V)	C	SAMSUNG	ProSens 500, 525 series	Green(19V)	A	SONY	VAIO PCG-729	Green(19V)	A	SONY	VAIO PCG-F520	Green(19V)	A	SONY	VAIO PCG-XE17	Green(19V)	A	SONY	VAIO PCG-Z505SX	Green(19V)	A
IBM	Thinkpad 600X	Blue(16V)	C	SHARP	PC3000 Series	Green(19V)	C	SONY	VAIO PCG-731	Green(19V)	A	SONY	VAIO PCG-F540	Green(19V)	A	SONY	VAIO PCG-XE7	Green(19V)	A	SONY	VAIO PictureBook PCG-C1X	Blue(16V)	A
IBM	Thinkpad 701	Blue(16V)	C	SHARP	PC9340T	Green(19V)	C	SONY	VAIO PCG-735	Green(19V)	A	SONY	VAIO PCG-F540K	Green(19V)	A	SONY	VAIO PCG-XG Series	Green(19V)	A	SONY	VAIO VX Series	Blue(16V)	A
IBM	Thinkpad 770	Blue(16V)	C	SONY	Valo FX103	Green(19V)	A	SONY	VAIO PCG-748	Green(19V)	A	SONY	VAIO PCG-F560	Green(19V)	A	SONY	VAIO PCG-XG18	Green(19V)	A	TOSHIBA	Portege 120	Purple(15V)	B
IBM	Thinkpad 770E	Blue(16V)	C	SONY	Valo FX105K	Green(19V)	A	SONY	VAIO PCG-800 Series	Green(19V)	A	SONY	VAIO PCG-F560K	Green(19V)	A	SONY	VAIO PCG-XG19	Green(19V)	A	TOSHIBA	Portege 2000	Purple(15V)	B
IBM	Thinkpad 770ED	Blue(16V)	C	SONY	Valo FX109K	Green(19V)	A	SONY	VAIO PCG-808	Green(19V)	A	SONY	VAIO PCG-F580	Green(19V)	A	SONY	VAIO PCG-XG28	Green(19V)	A	TOSHIBA	Portege 300	Purple(15V)	B
IBM	Thinkpad 770X	Blue(16V)	C	SONY	Valo FX120	Green(19V)	A	SONY	VAIO PCG-812	Green(19V)	A	SONY	VAIO PCG-F580K	Green(19V)	A	SONY	VAIO PCG-XG28k	Green(19V)	A	TOSHIBA	Portege 320	Purple(15V)	B
IBM	Thinkpad 770Z	Blue(16V)	C	SONY	Valo FX170	Green(19V)	A	SONY	VAIO PCG-818	Green(19V)	A	SONY	VAIO PCG-F590	Green(19V)	A	SONY	VAIO PCG-XG29	Green(19V)	A	TOSHIBA	Portege 3500	Purple(15V)	B
IBM	Thinkpad I1720	Blue(16V)	C	SONY	Valo FX190	Green(19V)	A	SONY	VAIO PCG-838	Green(19V)	A	SONY	VAIO PCG-F590K	Green(19V)	A	SONY	VAIO PCG-XG38	Green(19V)	A	TOSHIBA	Portege 4000 Series	Purple(15V)	B
IBM	Thinkpad I1721	Blue(16V)	C	SONY	Valo FX200	Green(19V)	A	SONY	VAIO PCG-C1X	Blue(16V)	A	SONY	VAIO PCG-F630	Green(19V)	A	SONY	VAIO PCG-XG39	Green(19V)	A	TOSHIBA	Portege 4005 Series	Purple(15V)	B
NEC	Ready 120T	Purple(15V)	D	SONY	Valo FX270	Green(19V)	A	SONY	VAIO PCG-F150	Green(19V)	A	SONY	VAIO PCG-F660	Green(19V)	A	SONY	VAIO PCG-XG39k	Green(19V)	A	TOSHIBA	Portege 4010 Series	Purple(15V)	B
NEC	Ready 220T, 330T, 340T, 360T series, VX series	Green(19V)	C	SONY	Valo FX770K	Green(19V)	A	SONY	VAIO PCG-F160	Green(19V)	A	SONY	VAIO PCG-F670	Green(19V)	A	SONY	VAIO PCG-XG9	Green(19V)	A	TOSHIBA	Portege 610	Purple(15V)	B
NEC	Versa SX, LX, LXI series	Purple(15V)	B	SONY	Valo FX800	Green(19V)	A	SONY	VAIO PCG-F180	Green(19V)	A	SONY	VAIO PCG-F680	Green(19V)	A	SONY	VAIO PCG-Z505	Green(19V)	A	TOSHIBA	Portege 620	Purple(15V)	B
PANASONIC	CF01	Blue(16V)	A	SONY	Valo FX880K	Green(19V)	A	SONY	VAIO PCG-F190	Green(19V)	A	SONY	VAIO PCG-F690	Green(19V)	A	SONY	VAIO PCG-Z505 Series	Green(19V)	A	TOSHIBA	Portege 650	Purple(15V)	B
PANASONIC	CF17	Blue(16V)	A	SONY	Valo FXA32	Green(19V)	A	SONY	VAIO PCG-F250	Green(19V)	A	SONY	VAIO PCG-F707	Green(19V)	A	SONY	VAIO PCG-Z505FA	Green(19V)	A	TOSHIBA	Portege 660	Purple(15V)	B
PANASONIC	CF25	Blue(16V)	A	SONY	Valo FXA33	Green(19V)	A	SONY	VAIO PCG-F270	Green(19V)	A	SONY	VAIO PCG-F801A	Green(19V)	A	SONY	VAIO PCG-Z505GA	Green(19V)	A	TOSHIBA	R100	Purple(15V)	B
PANASONIC	CF27	Blue(16V)	A	SONY	Valo FXA36	Green(19V)	A	SONY	VAIO PCG-F280	Green(19V)	A	SONY	VAIO PCG-F807	Green(19V)	A	SONY	VAIO PCG-Z505GAH	Green(19V)	A	TOSHIBA	Satellite 1000	Purple(15V)	B
PANASONIC	CF28	Blue(16V)	A	SONY	VAIO GR Series	Blue(16V)	A	SONY	VAIO PCG-F290	Green(19V)	A	SONY	VAIO PCG-GR100K	Blue(16V)	A	SONY	VAIO PCG-Z505GAM	Green(19V)	A	TOSHIBA	Satellite 1110	Purple(15V)	B
PANASONIC	CF33	Blue(16V)	A	SONY	VAIO GRX Series	Green(19V)	A	SONY	VAIO PCG-F340	Green(19V)	A	SONY	VAIO PCG-R505 Series	Green(19V)	A	SONY	VAIO PCG-Z505HE	Green(19V)	A	TOSHIBA	Satellite 1130	Purple(15V)	B
PANASONIC	CF34	Blue(16V)	A	SONY	VAIO NV Series	Green(19V)	A	SONY	VAIO PCG-F350	Green(19V)	A	SONY	VAIO PCG-R505CT	Green(19V)	A	SONY	VAIO PCG-Z505HS	Green(19V)	A	TOSHIBA	Satellite 1135	Purple(15V)	B
PANASONIC	CF35	Blue(16V)	A	SONY	VAIO PCG-505F	Blue(16V)	A	SONY	VAIO PCG-F360	Green(19V)	A	SONY	VAIO PCG-R505DT	Green(19V)	A	SONY	VAIO PCG-Z505HSK	Green(19V)	A	TOSHIBA	Satellite 1400 Series	Purple(15V)	B
PANASONIC	CF37	Blue(16V)	A	SONY	VAIO PCG-505FX	Blue(16V)	A	SONY	VAIO PCG-F370	Green(19V)	A	SONY	VAIO PCG-R505TE	Green(19V)	A	SONY	VAIO PCG-Z505JE	Green(19V)	A	TOSHIBA	Satellite 1500	Purple(15V)	B

## Compatible Notebook Computers Model List

The Setup Procedures of the power adapter could be founded in the User Manual. From this page, you could easily find what "Tip" and "Voltage Selection Device" is suitable for your Notebook Computer model.

Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.		
TOSHIBA	Satellite 1555	Purple(15V)	B	TOSHIBA	Satellite 2515	Purple(15V)	B	TOSHIBA	Satellite 4060	Purple(15V)	B	TOSHIBA	Tecra 530	Purple(15V)	B	WINBOOK	Winbook X1	Green(19V)	C						
TOSHIBA	Satellite 1600	Purple(15V)	B	TOSHIBA	Satellite 2520	Purple(15V)	B	TOSHIBA	Satellite 4070	Purple(15V)	B	TOSHIBA	Tecra 550	Purple(15V)	B	WINBOOK	Winbook XP	Green(19V)	C						
TOSHIBA	Satellite 1605	Green(19V)	C	TOSHIBA	Satellite 2525	Purple(15V)	B	TOSHIBA	Satellite 4080	Purple(15V)	B	TOSHIBA	Tecra 700	Purple(15V)	B	WINBOOK	Winbook XP5	Green(19V)	C						
TOSHIBA	Satellite 1615	Purple(15V)	B	TOSHIBA	Satellite 2535	Purple(15V)	B	TOSHIBA	Satellite 4090	Purple(15V)	B	TOSHIBA	Tecra 710	Purple(15V)	B	WINBOOK	Winbook XP5Pro	Green(19V)	D						
TOSHIBA	Satellite 1625	Green(19V)	C	TOSHIBA	Satellite 2540	Purple(15V)	B	TOSHIBA	Satellite 4100	Purple(15V)	B	TOSHIBA	Tecra 720	Purple(15V)	B	WINBOOK	Winbook Z	Green(19V)	D						
TOSHIBA	Satellite 1675	Green(19V)	C	TOSHIBA	Satellite 2545	Purple(15V)	B	TOSHIBA	Satellite 4320	Purple(15V)	B	TOSHIBA	Tecra 720CDT	Purple(15V)	B	WINBOOK	Winbook Z1	Green(19V)	C						
TOSHIBA	Satellite 1695	Green(19V)	C	TOSHIBA	Satellite 2590	Purple(15V)	B	TOSHIBA	Satellite 4340	Purple(15V)	B	TOSHIBA	Tecra 730	Purple(15V)	B										
TOSHIBA	Satellite 1700	Purple(15V)	B	TOSHIBA	Satellite 2595	Purple(15V)	B	TOSHIBA	Satellite 4360	Purple(15V)	B	TOSHIBA	Tecra 730X	Purple(15V)	B										
TOSHIBA	Satellite 1715 XCDS	Green(19V)	C	TOSHIBA	Satellite 2610	Purple(15V)	B	TOSHIBA	Satellite 5005-S504	Purple(15V)	B	TOSHIBA	Tecra 740	Purple(15V)	B										
TOSHIBA	Satellite 1730 Series	Green(19V)	C	TOSHIBA	Satellite 2615	Purple(15V)	B	TOSHIBA	Satellite 5100 Series	Purple(15V)	B	TOSHIBA	Tecra 750	Purple(15V)	B										
TOSHIBA	Satellite 1735 Series	Green(19V)	C	TOSHIBA	Satellite 2650XDVD	Purple(15V)	B	TOSHIBA	Satellite 5200	Purple(15V)	B	TOSHIBA	Tecra 780	Purple(15V)	B										
TOSHIBA	Satellite 1750 Series	Green(19V)	C	TOSHIBA	Satellite 2675	Purple(15V)	B	TOSHIBA	Satellite Pro 4220 Series	Purple(15V)	B	TOSHIBA	Tecra 8000	Purple(15V)	B										
TOSHIBA	Satellite 1800	Purple(15V)	B	TOSHIBA	Satellite 2715	Purple(15V)	B	TOSHIBA	Satellite Pro 4260	Purple(15V)	B	TOSHIBA	Tecra 8100 Series	Purple(15V)	B										
TOSHIBA	Satellite 1805	Purple(15V)	B	TOSHIBA	Satellite 2755	Purple(15V)	B	TOSHIBA	Satellite Pro 4280	Purple(15V)	B	TOSHIBA	Tecra 8200	Purple(15V)	B										
TOSHIBA	Satellite 2060	Purple(15V)	B	TOSHIBA	Satellite 2775	Purple(15V)	B	TOSHIBA	Satellite Pro 4300 Series	Purple(15V)	B	TOSHIBA	Tecra 9000	Purple(15V)	B										
TOSHIBA	Satellite 2065	Purple(15V)	B	TOSHIBA	Satellite 2800 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 440 Series	Purple(15V)	B	TOSHIBA	Tecra 9100	Purple(15V)	B										
TOSHIBA	Satellite 2095	Purple(15V)	B	TOSHIBA	Satellite 2800T	Purple(15V)	B	TOSHIBA	Satellite Pro 445 Series	Purple(15V)	B	TOSHIBA	Tecra M1	Purple(15V)	B										
TOSHIBA	Satellite 2100	Purple(15V)	B	TOSHIBA	Satellite 2805 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 460 Series	Purple(15V)	B	TOSHIBA	Tecra S1	Purple(15V)	B										
TOSHIBA	Satellite 2105	Purple(15V)	B	TOSHIBA	Satellite 3005	Green(19V)	C	TOSHIBA	Satellite Pro 4600 Series	Purple(15V)	B	TWINHEAD	P88T	Green(19V)	C										
TOSHIBA	Satellite 210CS	Purple(15V)	B	TOSHIBA	Satellite 305 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 465 Series	Purple(15V)	B	TWINHEAD	SlimNote GX2	Green(19V)	D										
TOSHIBA	Satellite 2140	Purple(15V)	B	TOSHIBA	Satellite 315 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 470 Series	Purple(15V)	B	TWINHEAD	SlimNote VXE Series, 602TZ	Green(19V)	C										
TOSHIBA	Satellite 2180	Purple(15V)	B	TOSHIBA	Satellite 320 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 480 Series	Purple(15V)	B	TWINHEAD	Figaro Celeron 300CTZ, 33DTG, 266DTZ	Green(19V)	C										
TOSHIBA	Satellite 220	Purple(15V)	B	TOSHIBA	Satellite 325 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 490 Series	Purple(15V)	B	TWINHEAD	Figaro 300TG, VX3 500TZ, 500TG, P88T, 600	Green(19V)	C										
TOSHIBA	Satellite 2210	Purple(15V)	B	TOSHIBA	Satellite 330 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 490X	Purple(15V)	B	TWINHEAD	Marco Polo, S Body, Power Slim 600, 601TZ	Green(19V)	D										
TOSHIBA	Satellite 225	Purple(15V)	B	TOSHIBA	Satellite 335 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 6000	Purple(15V)	B	TWINHEAD	N2380	Black(20V)	C										
TOSHIBA	Satellite 2250	Purple(15V)	B	TOSHIBA	Satellite 4000	Purple(15V)	B	TOSHIBA	Satellite Pro 6100	Purple(15V)	B	TWINHEAD	N2700	Red(18V)	C										
TOSHIBA	Satellite 230CX	Purple(15V)	B	TOSHIBA	Satellite 4005	Purple(15V)	B	TOSHIBA	Satellite Pro M10	Purple(15V)	B	WINBOOK	Winbook CJ	Green(19V)	D										
TOSHIBA	Satellite 2400	Purple(15V)	B	TOSHIBA	Satellite 4010	Purple(15V)	B	TOSHIBA	Satellite Pro M15	Purple(15V)	B	WINBOOK	Winbook FX	Green(19V)	D										
TOSHIBA	Satellite 2405	Purple(15V)	B	TOSHIBA	Satellite 4015	Purple(15V)	B	TOSHIBA	TE2100	Purple(15V)	B	WINBOOK	Winbook J1	Green(19V)	C										
TOSHIBA	Satellite 2410	Purple(15V)	B	TOSHIBA	Satellite 4020	Purple(15V)	B	TOSHIBA	Tecra 510CDT	Purple(15V)	B	WINBOOK	Winbook SI	Green(19V)	C										
TOSHIBA	Satellite 2415	Purple(15V)	B	TOSHIBA	Satellite 4025	Purple(15V)	B	TOSHIBA	Tecra 520	Purple(15V)	B	WINBOOK	Winbook SI2	Green(19V)	C										
TOSHIBA	Satellite 2505	Purple(15V)	B	TOSHIBA	Satellite 4030	Purple(15V)	B	TOSHIBA	Tecra 520CDS/CDT	Purple(15V)	B	WINBOOK	Winbook X	Green(19V)	D										

2003.05.23