

It is strongly recommended that a 1A fuse (not supplied) should be linked by series on the positive side of power supply

