






CAUTION



The lamp do not connected to the vehicle battery directly.



With Engine Start Sensor Function.



Without Engine Start Sensor Function.

